


acorn[®] 450

corded robotic pool cleaner




Quick Start Guide


In this box




Acorn 450 Pool Cleaner




Control Box + 15m Cable



1.5m Power Cable



Hook



Quick Start Guide




BEFORE YOU START


Before installing your new Acorn robotic cleaner for the first time, it is essential that you read and familiarise yourself with all the instructions and safety warnings contained in this Quick Start Guide.

A. Setting up your Acorn 450

- ② Uncoil the 15m Power Cord from the Cleaner and which is attached to the Control Box.




NOTE: DO NOT USE AN EXTENSION CORD!



B. Operating your Acorn 450 Pool Cleaner from the Controller Box


- 1 Select the cleaning mode from one of the four options below the screen on the Control Box.
- 2 Press the Cleaner Start button  to the left of the screen.
 - Use the Cleaner Pause button  to pause cleaning.
 - Use the Cleaner Stop button  to stop the cleaner.

- 3 Using the  or  keys, adjust the cleaner program.




C. Removing your Acorn 450 Pool Cleaner from the pool

- ① Insert the hook, which comes with your Acorn 450, into the end of a pool pole.



- ③ With the hook still around the Acorn's handle, lift the cleaner until it breaks the surface of the pool.




- ④ Remove the cleaner by grabbing the handle with your hand and lifting it clear of the pool.

Hold the cleaner above the water and allow it to drain.

- ⑥ Leave your Acorn 450 at the side of the pool, allowing it to dry before cleaning the debris box, ready for it's next swim.

- ⑦ Leave the pump to run for 30 minutes after removing the cleaner from the pool.

- ② Place the hook under the handle of your Acorn 450 and drag it to the side of the pool



- ⑤ When the water has drained from the cleaner, gently lower it to rest on all four wheels by the side of the pool.

